$\mathsf{MODEL} \colon DM25555$

ASSEMBLY INSTRUCTION

Important note: - Place all wooden part on a clean and smooth surface such as rug or carpet to avoid the part from being scratch.

- Please follow the assembly instruction step by step.
- Do not tighten all screw until the chair is fully set-up.

No	Hardware List		Qty.
A	JCBC M6 x 35mm		4 pcs
В	JCBC M6 x 60mm	 (0	8 pcs
С	JCBC M6 x 80mm		8 pcs
D	Spring Washer	٥	20 pcs
Е	Flat Washer	©	20 pcs
F	CSK M4 x 32mm	Ø man	8 pcs
G	Allen Key M4		1 pc

No	Part List	Qty.
1	Backrest	2 pcs
2	Box Seat	2 pcs
3	Front Leg	4 pcs
4	Cushion	2 pcs









