ASSEMBLY INSTRUCTIONS INSTRUCTIONS POUR L 'ASSEMBLAGE





 $MODEL \qquad : BM24128\text{-}EK / BM24128\text{-}QB$

DESC. : KING / QUEEN BED

SLAT SYSTEM : 13PCS

TV STAND : Suitable for

- TV 50" for KING BED and below

- TV 40" for QUEEN BED and below

ASSEMBLY INSTRUCTIONS

ITEM NO: 3722
KING/QUEEN BED

(BOX 1) BOX OF HEADBOARD

ITEM	DRAWING	DESCRIPTION	QTY
A		HEADBOARD	1
В		ADAPTER PLUG for LED LIGHT (Located inside the black woven cover behind the Headboard)	1

(BOX 2) BOX OF FOOTBOARD

ITEM	DRAWING	DESCRIPTION	QTY
C		FOOTBOARD STORAGE	1
D		HEADBOARD LEG - LEFT	1
E		HEADBOARD LEG - RIGHT	1
F		HEADBOARD LEG SUPPORT	2
G	9	BED LEG	8
Н		WOODEN SUPPORT	3
I	600	CENTER RAIL SUPPORT	1
J		TV MOUNT BRACKET	1
K	(SP)	TV STAND REMOTE	1


(BOX 3) BOX OF SIDE RAIL

ITEM	DRAWING	DESCRIPTION	QTY
M		SIDE RAIL - LEFT	1
N		SIDE RAIL - RIGHT	1
О		SLAT WITH 3 HOLES	3
P		SLAT WITH 2 HOLES	10
Q		CENTER RAIL	1

(BOX 2) BOX OF FOOTBOARD HARDWARE LIST

ITEM	DRAWING	DESCRIPTION	QTY
1		ALLEN KEY WITH BALL (M4)	1
2	O TOTAL DE LA CONTRACTION DE L	CONNECTION BOLT (M6 x 30mm) W/SPRING WASHER & WASHER MEDIUM	8
3	O TOTAL DE LA COLONIA DE LA CO	CONNECTION BOLT (M6 x 40mm) W/SPRING WASHER & WASHER MEDIUM	10
4	0 mm	JCBC BOLT (M6 x 40mm)	2
5		JCBC BOLT (M6 x 60mm)	3
6		ADJUSTER	3
7	(3)mmm	CSK SCREW (M4 x 32mm)	35
8		SCREW DRIVER (*)	1

(*) The Manufacturer does not provide item 8.



V0 (24-11)

THE HARDWARE IS LOCATED IN THE PACKING ITEMS.

FIREPLACE REMOTE
**Battery is Not Provided


P

 \mathbf{L}

NOTE: MUST TIGHTEN BOLTS & SCREWS PERIODICALLY. WITH USE BOLTS & SCREWS MAY BECOME LOOSE. CHECK TIGHTNESS OF ALL BOLTS & SCREWS EVERY 6-8 WEEKS.


STEP 1

Remove the Cover at the Bottom of the Footboard Storage (C).




Take Out and Remove the Headboard Leg (D & E), Headboard Leg Support (F), Bed Leg (G), Wooden Support (H) and Center Rail Support (I) which are Inside the Box.


STEP 2



STEP 3




STEP 4




THE HARDWARE IS LOCATED IN THE PACKING ITEMS.


NOTE : MUST TIGHTEN BOLTS & SCREWS PERIODICALLY. WITH USE BOLTS & SCREWS MAY BECOME LOOSE. CHECK TIGHTNESS OF ALL BOLTS & SCREWS EVERY 6-8 WEEKS.




NOTE: MUST TIGHTEN BOLTS & SCREWS PERIODICALLY. WITH USE BOLTS & SCREWS MAY BECOME LOOSE. CHECK TIGHTNESS OF ALL BOLTS & SCREWS EVERY 6-8 WEEKS.




NOTE : MUST TIGHTEN BOLTS & SCREWS PERIODICALLY. WITH USE BOLTS & SCREWS MAY BECOME LOOSE. CHECK TIGHTNESS OF ALL BOLTS & SCREWS EVERY 6-8 WEEKS.




NOTE: MUST TIGHTEN BOLTS & SCREWS PERIODICALLY. WITH USE BOLTS & SCREWS MAY BECOME LOOSE. CHECK TIGHTNESS OF ALL BOLTS & SCREWS EVERY 6-8 WEEKS.




NOTE : MUST TIGHTEN BOLTS & SCREWS PERIODICALLY. WITH USE BOLTS & SCREWS MAY BECOME LOOSE. CHECK TIGHTNESS OF ALL BOLTS & SCREWS EVERY 6-8 WEEKS.



NOTE : MUST TIGHTEN BOLTS & SCREWS PERIODICALLY. WITH USE BOLTS & SCREWS MAY BECOME LOOSE. CHECK TIGHTNESS OF ALL BOLTS & SCREWS EVERY 6-8 WEEKS.



NOTE : MUST TIGHTEN BOLTS & SCREWS PERIODICALLY. WITH USE BOLTS & SCREWS MAY BECOME LOOSE. CHECK TIGHTNESS OF ALL BOLTS & SCREWS EVERY 6-8 WEEKS.



NOTE : MUST TIGHTEN BOLTS & SCREWS PERIODICALLY. WITH USE BOLTS & SCREWS MAY BECOME LOOSE. CHECK TIGHTNESS OF ALL BOLTS & SCREWS EVERY 6-8 WEEKS.

CLEANING INSTRUCTION

ASSEMBLY COMPLETE