


ASSEMBLY INSTRUCTIONS

ITEM NUMBER: AV25016


DESCRIPTION: END TABLE

Thank you for purchasing this quality product. Please read instructions carefully prior to assembly. Check carefully for small parts which may have come loose during transportation inside all the boxes. Remove from boxes and place all parts and components on soft surface such as carpet. Blanket or furniture pad. Identify and verify all parts and hardware as specified below.

PART LIST

A		TABLE TOP	1 PC
B		LEGS	4 PCS

HARDWARE LIST

C		ALLEN KEY	1 PC
D		BOLT 5/16x80mm	8 PCS
G		FLAT WASHER Ø5/16x22mm	8 PCS
E		LOCK WASHER Ø5/16	8 PCS






- ASSEMBLY TIPS:**
1. Remove hardware from box and sort by size.
 2. Please check to see that all hardware and parts are present prior to start of assembly.
 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.
- WARNING!**
1. Don't attempt to repair or modify parts that are broken or defective. Please contact us immediately.
 2. This product is for home use only and not intended for commercial establishments.
 3. Minimum of 2 people are required for assembly.

***How to assemble:**

STEP 1:



COMPLETE :

Your product is ready for you to enjoy.

