







# MODEL: DM24118

Important note: - Place all wooden part on a clean and smooth surface such as rug or carpet to avoid the part from being scratch.  
- Please follow the assembly instruction step by step.  
- Do not tighten all screw until the chair is fully set-up.



No	Hardware List	Qty.
A	JCBC M6 x 35mm	4 pcs
B	JCBC M6 x 60mm	8 pcs
C	JCBC M6 x 80mm	8 pcs
D	M6 Spring Washer	20 pcs
E	M6 Flat Washer	20 pcs
F	CSK M4 x 32mm	8 pcs
G	CSK M4 x 38mm	8 pcs
H	Allen Key M4	1 pc







No	Part List	Qty.
1	Backrest	2 pcs
2	Box Seat	2 pcs
3	Front Leg	4 pcs
4	Wooden Slat / Cushion	2 pcs
5	Stretcher	4 pcs

COMPLETED ASSEMBLY



# MODEL: DM24118

Important note: - Place all wooden part on a clean and smooth surface such as rug or carpet to avoid the part from being scratch.  
- Please follow the assembly instruction step by step.  
- Do not tighten all screw until the chair is fully set-up.



No	Hardware List	Qty.
A	JCBC M6 x 35mm	4 pcs
B	JCBC M6 x 60mm	8 pcs
C	JCBC M6 x 80mm	8 pcs
D	M6 Spring Washer	20 pcs
E	M6 Flat Washer	20 pcs
F	CSK M4 x 32mm	8 pcs
G	CSK M4 x 38mm	8 pcs
H	Allen Key M4	1 pc

No	Part List	Qty.
1	Backrest	2 pcs
2	Box Seat	2 pcs
3	Front Leg	4 pcs
4	Wooden Slat / Cushion	2 pcs
5	Stretcher	4 pcs

COMPLETED ASSEMBLY

