









Model: **DM24118**

Important note: - Place all wooden part on a clean and smooth surface such as rug or carpet to avoid the part from being scratch.  
- Please follow the assembly instruction step by step.  
- Do not tighten all screw until the table is fully set-up.

ASSEMBLY INSTRUCTION

No	Hardware List	Qty.
A	JCBC M6 x 35mm 	16 pcs
B	M6 Flat Washer 	16 pcs
C	CSK M4 x 32mm 	12 pcs
D	Adjustable 	4 pcs
E	Allen Key M4 	1 pc

No	Part List	Qty.
1	Table Top	1 pc
2	Table Top Support	1 pcs
3	Table Leg	4 pcs
4	Bottom Panel	1 pc








COMPLETED ASSEMBLY




Model: **DM24118**

Important note: - Place all wooden part on a clean and smooth surface such as rug or carpet to avoid the part from being scratch.  
- Please follow the assembly instruction step by step.  
- Do not tighten all screw until the table is fully set-up.

ASSEMBLY INSTRUCTION

No	Hardware List	Qty.
A	JCBC M6 x 35mm 	16 pcs
B	M6 Flat Washer 	16 pcs
C	CSK M4 x 32mm 	12 pcs
D	Adjustable 	4 pcs
E	Allen Key M4 	1 pc

No	Part List	Qty.
1	Table Top	1 pc
2	Table Top Support	1 pcs
3	Table Leg	4 pcs
4	Bottom Panel	1 pc



COMPLETED ASSEMBLY