







Model: **DM24119-DT**


ASSEMBLY INSTRUCTION

Important note: - Place all wooden part on a clean and smooth surface such as rug or carpet to avoid the part from being scratch.
- Please follow the assembly instruction step by step.
- Do not tighten all screw until the table is fully set-up.



No	Hardware List	Qty.
A	JCBC Screw 	8 pcs
B	Spring Washer 	8 pcs
C	Flat Washer 	8 pcs
D	Allen Key 	1 pc

No	Part List	Qty.
1	Table Top	1 pc
2	Table Leg	4 pcs









COMPLETED ASSEMBLY

Model: **DM24119-DT**


ASSEMBLY INSTRUCTION

Important note: - Place all wooden part on a clean and smooth surface such as rug or carpet to avoid the part from being scratch.
- Please follow the assembly instruction step by step.
- Do not tighten all screw until the table is fully set-up.



No	Hardware List	Qty.
A	JCBC Screw 	8 pcs
B	Spring Washer 	8 pcs
C	Flat Washer 	8 pcs
D	Allen Key 	1 pc

No	Part List	Qty.
1	Table Top	1 pc
2	Table Leg	4 pcs



COMPLETED ASSEMBLY