


# ASSEMBLY INSTRUCTIONS

MODEL: BE24051-BCH


Read this instruction carefully. Refer hardware and furniture parts list for guidance. Be sure all parts are complete before assembling. Place all wooden furniture part on a clean and flat soft surface to prevent scratches. Refer steps provided as assembling guide.

PART LIST		
ITEM	DESCRIPTION	QTY
A	Cushion	1 PC
B	Box seat	1 SET
C	Leg	2 SET
D	Stretcher	2 PCS


HARDWARE LIST		
ITEM	DESCRIPTION	QTY
1	JCBC Screw M6 x 45mm	4 PCS
2	Spring Washer M6 x 13mm	4 PCS
3	Flat Washer M6 x 16.5mm	4 PCS
4	Hex Nut M8 x 14mm	4 PCS
5	Spring Washer M8 x 14mm	4 PCS
6	Flat Washer M8 x 22mm	4 PCS
7	Spanner 12.8mm	1 PC
8	Allen Key Small M4 x 55mm	1 PC
9	CSK Screw M4 x 38mm	12 PCS





## STEP 1



## STEP 2



## STEP 3



COMPLETED ASSEMBLY