




MODEL: DM25607






Important note: - Place all wooden part on a clean and smooth surface such as rug or carpet to avoid the part from being scratch.
 - Please follow the assembly instruction step by step.
 - Do not tighten all screw until the chair is fully set-up.



COMPLETED ASSEMBLY





ASSEMBLY INSTRUCTION

No	Hardware List	Qty.
A	JCBC M6 x 60mm 	8 pcs
B	JCBC M6 x 50mm 	8 pcs
C	Spring Washer M6 	16 pcs
D	Flat Washer M6 x 19mm 	16 pcs
E	Allen Key M4 	1 pc


No	Part List	Qty.
1	Backrest with Box Seat	2 pcs
2	Front Leg	4 pcs
3	Back Leg	4 pcs

MODEL: DM25607






Important note: - Place all wooden part on a clean and smooth surface such as rug or carpet to avoid the part from being scratch.
 - Please follow the assembly instruction step by step.
 - Do not tighten all screw until the chair is fully set-up.



COMPLETED ASSEMBLY



ASSEMBLY INSTRUCTION

No	Hardware List	Qty.
A	JCBC M6 x 60mm 	8 pcs
B	JCBC M6 x 50mm 	8 pcs
C	Spring Washer M6 	16 pcs
D	Flat Washer M6 x 19mm 	16 pcs
E	Allen Key M4 	1 pc

No	Part List	Qty.
1	Backrest with Box Seat	2 pcs
2	Front Leg	4 pcs
3	Back Leg	4 pcs