




DV24034-DT **DINING TABLE**

ASSEMBLY INSTRUCTION






ASSEMBLY TIPS:

1. Remove hardware from box and sort by size
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

**Warning!**

1. Don't attempt to repair or modify parts that are broken or defective, Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.

PARTS IDENTIFICATION

A		TABLE TOP	1 PC
B		LEAF TOP	2 PCS
C		TABLE LEG	2 PCS
D		STRETCHER	1 PC
E		COVER	2 PCS

ASSEMBLY TIPS:


1. Remove hardware from box and sort by size
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

**Warning!**

1. Don't attempt to repair or modify parts that are broken or defective, Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.

HARDWARE IDENTIFICATION

1		BOLT Ø5/16"*3 1/4"	2 PCS
2		BOLT Ø5/16"*2"	8 PCS
3		LOCK WASHER Ø5/16"	10 PCS
4		FLAT WASHER Ø5/16"*16MM	10 PCS
5		ALLEN KEY 4MM	1 PC

STEP 1.

ASSEMBLY TIPS:


1. Remove hardware from box and sort by size
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.




Warning!

1. Don't attempt to repair or modify parts that are broken or defective, Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.

STEP 2.




STEP 3.





DV24034-BCH BENCH

ASSEMBLY INSTRUCTION





ASSEMBLY TIPS:

1. Remove hardware from box and sort by size
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

**Warning!**

1. Don't attempt to repair or modify parts that are broken or defective, Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.

PARTS IDENTIFICATION**A****SEAT BOARD****1 PC****B****LEG****2 PCS****C****STRETCHER****1 PC****D****COVER****2 PCS**

ASSEMBLY TIPS:


1. Remove hardware from box and sort by size
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

**Warning!**

1. Don't attempt to repair or modify parts that are broken or defective, Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.

HARDWARE IDENTIFICATION

1		BOLT Ø5/16"*3 1/4"	2 PCS
2		BOLT Ø5/16"*1 1/2"	8 PCS
3		LOCK WASHER Ø5/16"	10 PCS
4		FLAT WASHER Ø5/16"*16MM	10 PCS
5		ALLEN KEY 4MM	1 PC

STEP 1.

ASSEMBLY TIPS:


1. Remove hardware from box and sort by size
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



Warning!

1. Don't attempt to repair or modify parts that are broken or defective, Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.


STEP 2.





DV24034-SC
SIDE CHAIR

ASSEMBLY INSTRUCTION







ASSEMBLY TIPS:

1. Remove hardware from box and sort by size
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

**Warning!**

1. Don't attempt to repair or modify parts that are broken or defective, Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.

PARTS IDENTIFICATION**A****CHAIR BACK****1 PC****B****SEAT FRAME****1 PC****C****LEFT FRONT LEG****1 PC****D****RIGHT FRONT LEG****1 PC****E****STRETCHER****2 PCS**

ASSEMBLY TIPS:


1. Remove hardware from box and sort by size
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.

**Warning!**

1. Don't attempt to repair or modify parts that are broken or defective, Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.

HARDWARE IDENTIFICATION

1		BOLT Ø5/16"*3 "	4 PCS
2		BOLT Ø5/16"*2 1/4"	4 PCS
3		BOLT Ø5/16"*1 1/2"	2 PCS
4		LOCK WASHER Ø5/16"	10 PCS
5		FLAT WASHER Ø5/16"*16MM	10 PCS
6		ALLEN KEY 4MM	1 PC
7		WOOD SCREW (#4x38mm)	4 PC

STEP 1.

ASSEMBLY TIPS:

1. Remove hardware from box and sort by size
2. Please check to see that all hardware and parts are present prior to start of assembly.
3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



Warning!

1. Don't attempt to repair or modify parts that are broken or defective, Please contact the store immediately.
2. This product is for home use only and not intended for commercial establishment.

STEP 2.

