

ASSEMBLY INSTRUCTION

Bel Furniture


ITEM#: CV2836+CV3836+CV4836

DESCRIPTION: HEADBOARD BOOKCASE

Thank you for purchasing this quality product.

Please read instructions carefully prior to assembly

Check carefully for small parts which may have come loose during transportation inside all the boxes. Remove from boxes and place all parts and components on soft surface such as carpet, blanket or furniture pad. Identify and verify all parts and hardware as specified below.



Assembly Tips:






- * Do not tighten screws and bolts until final steps of the assembly
- * This assembly may require additional help (2 person set up)







ASSEMBLY INSTRUCTION

Bel Furniture

ITEM#: CV2836+CV3836+CV4836

DESCRIPTION: HEADBOARD BOOKCASE

PART LIST							
A	TOP PANEL		1PC	D	TOP BACK RAIL		1PC
B	SIDE PANEL		2PCS	E	BOTTOM BACK RAIL		2PCS
C	SHELF PANEL		2PCS				


HARDWARE LIST							
1	BOLT (1/4 x 50mm)		12PCS	4	ALLEN KEY (L60 x 4mm)		1PC
2	INSERT NUT (1/4 x 13mm)		12PCS	5	SCREWS (Ø6 x 30mm)		6PCS
3	WOODEN DOWEL (Ø8 x 30mm)		12PCS	6	SCREWS (Ø6 x 40mm)		3PCS

ASSEMBLY INSTRUCTION

Bel Furniture

ITEM#: CV2836+CV3836+CV4836

DESCRIPTION: HEADBOARD BOOKCASE



ASSEMBLY INSTRUCTION

Bel Furniture

ITEM#: CV2836+CV3836+CV4836

DESCRIPTION: HEADBOARD BOOKCASE

