
ASSEMBLY INSTRUCTIONS


MODEL: BE24054-CHDT


Read this instruction carefully. Refer hardware and furniture parts list for guidance. Be sure all parts are complete, before assembling. Place all wooden furniture part on a clean and flat soft surface to prevent scratched. Refer steps provided as assembling guide.


PART LIST			
ITEM	DESCRIPTION	QTY	
A	Table Top	1 PC	
В	Table Leg with Back Panel	1 SET	
C	Table Leg	1 SET	
D	Side Panel	2 PCS	
E	Top Panel	1 PC	
F	Center Panel	1 PC	
G	Bottom Panel	1 PC	
Н	Door	1 PC	
1-1	Rack Panel	1 PC	
1-2	Rack Panel	1 PC	
1-3	Rack Panel	1 PC	
1-4	Rack Panel	1 PC	


HARDWARE LIST			
ITEM	DESCRIPTION		QTY
1	JCBC Screw M6 x 40mm		8 PCS
2	JCBC Screw M8 x 50mm		4 PCS
3	Spring Washer M8 x 14mm		4 PCS
4	Flat Washer M8 x 22mm		4 PCS
5	CSK M4 x 25mm	**************************************	6 PCS
6	Allen Key M5		1 PC
7	Allen Key M4 x 110		1 PC
8	Adjuster $\frac{7}{8}$ "		4 PCS
9	Flat Washer M7 x 16mm		8 PCS



























STEP 1









Attach part (D) with part (B). Do not Tighten any hardware completely!



Insert Panel (F) and do alignment to fit panel (D) with panel (F) first, then tighten part(F) completely using 2 pcs CSK screw.







Insert panel (E) through side curve of top of panel (D).

