
ASSEMBLY INSTRUCTIONS


MODEL: BE24054-CHSC


Read this instruction carefully. Refer hardware and furniture parts list for guidance. Be sure all parts are complete before assembling. Place all wooden furniture part on a clean and flat soft surface to prevent scratches. Refer steps provided as assembling guide.


PART LIST			
ITEM	DESCRIPTION	QTY	
A	Backrest	1 PC	
В	Front Leg (Right & Left)	2 PCS	
C	Front Stretcher	1 PC	
D	Side Stretcher (Right & Left)	2 PCS	
E	Box Seat	1 PC	
F	Seat	1 PC	

HARDWARE LIST				
ITEM	DESCRIPTION		QTY	
1	JCBC Screw M6 x 80mm		4 PCS	
2	JCBC Screw M6 x 50mm		4 PCS	
3	JCBC Screw M6 x 35mm		2 PCS	
4	Spring Washer M6 x 13mm		10 PCS	
5	Flat Washer M7 x 19mm		10 PCS	
6	Allen Key M4 X 55mm		1 PC	
7	CSK Screw M4 x 38mm		6 PCS	
8	CSK Screw M4 x 30mm	✓CCCCC (X)	3 PCS	






















step i : Tighten sight stretcher (D).

step ii : Tighten back middle sight of box seat (E). step iii : Tighten back corner sight of box seat (E).

step iv: Tighten front leg (B).







COMPLETED ASSEMBLY