




ASSEMBLY INSTRUCTION'S

MODEL : DM26020 DINING CHAIR


Please follow Assembly Instruction carefully. Step by step.

PART LIST				HARDWARE LIST			
1	BACKREST		1pc	A	JCBC M6X45MM (black)		14pcs
2	CUSHION		1pc	B	SPRING WASHER M6 (black)		14pcs
3	BACK LEG		2 pcs	C	FLAT WASHER M6X13mm (black)		6pcs
4	FRONT LEG		2 pcs	D	FLAT WASHER M6X19mm (black)		8pcs
				E	WOOD DOWEL M8x30mm		4pcs
				F	ALLEN KEY M4 X 100mm		1pc


STEP 1




STEP 2



STEP 3




STEP 5



STEP 4

TIE ALL TIGHT



COMPLETED
ASSEMBLY